


Wiring Diagram

Yokogawa EXA PH202

BARBEN SENSOR: "C" TERMINATION

e.g. (B-V-546-X-XX-X-X-X-**C**-XX)



"IMPORTANT WARNINGS"




THE WIRING SHOWS A SENSOR WITH A SOLUTION GROUND. THIS OPTION IS DESIGNATED WITH WITH "GT", "UT" OR "LT" IN THE MODEL NUMBER.

e.g. (B-V-546-X-**LT**-X-X-X-X-X)

SENSORS WITHOUT A SOLUTION GROUND HAVE "FT", "ST" OR "DT" IN THE MODEL NUMBER.

e.g. (B-V-546-X-**DT**-X-X-X-X-X)

SENSORS WITHOUT A SOLUTION GROUND REQUIRE THAT SENSOR DIAGNOSTICS BE TURNED OFF IN THE TRANSMITTER AND A JUMPER IS INSTALLED AS SHOWN BELOW.



FOR SENSORS WITHOUT TEMPERATURE COMPENSATION DISREGARD TC WIRES. PROGRAM ANALYZER FOR MANUAL TEMPERATURE COMPENSATION.

NOTE - EXA PH202 ACCEPTS 2 WIRE TC's. USERS CAN WIRE AS SHOWN OR IF PREFERRED CUT BACK GREEN "TC RET" LEAD.



FOR ORP/REDOX SENSORS COAX CORE WILL BE LABELED AS "ORP IN" AND WIRING IS THE SAME.

ANALYZER CONFIGURATION & SETTINGS

• WIRING

Sensor Lead

"pH IN" - Coax Core Shield
 "REF" - White
 "SOL GRND" - Clear (Drain)
 "TC RET" - Green
 "TC SNSE" - Black
 "TC IN" - Red

Analyzer Terminal

(15) INPUT 1
 (13) INPUT 2
 (14) LE
 (12) TEMP
 (12) TEMP
 (11) TEMP

- SELECT PT100, PT1000, OR 3.01kΩ RTD BASED ON SENSOR
- SELECT AUTOMATIC TEMPERATURE COMPENSATION MODE
- USE YOKO SUPPLIED LOW IMPEDANCE JUMPER AT INPUT 2

Barben Analytical reserves the right to make technical changes or modify the contents of this document without prior notice. We reserve all rights in this document and in the subject matter and illustrations contained within.